


NETCOMM Simple Platform Set




Intermediate Platform Setup




Intermediate Platform Setup 2




Intermediate Platform Setup 3




Advanced Platform Setup





Advanced Platform Setup 2




Extension Possibilities








Internal Destinations



Pick up Groups/Extension Entry




Extension 2


Extension 1

Extension 3


Voicemail Options




Simple Phone Setup




Simple Office Network Setup




Piggyback Office Network Setup




Phone Power Requirements




Dual Router Office Setup



Dual WAN Router Setup



Small Office Server



VPN

